

HEATER HOSE ASSEMBLIES

ALSO KNOWN AS: HVAC HEATER HOSE ASSEMBLIES

Over 100 SKUs Available, Including Several Dorman Exclusives



626-315HP

Chrysler Town & Country,
Dodge Caravan 2016-11

Located in front of the fire
wall, behind the engine



Durably engineered to resist corrosion and leakage, our HVAC Heater Hoses limit the possibility of overheating and subsequent engine damage. Put engine worries to rest by preserving proper coolant circulation.

- Includes necessary clamps and fittings
- Constructed with premium materials to withstand the effects of engine and weather related stress
- Application specific design ensures direct-fit replacement

DORMAN OE FIX SOLUTION



OE PROBLEM:

Original Y-connectors are made of plastic and frequently leak due to cracking



Dorman upgraded the Y-connector material to aluminum for increased durability and a longer service life

ALSO AVAILABLE



626-549

Chevrolet Malibu 2006-04, Pontiac G6 2006-05

Think It's Dealer Only? **Check Dorman First!**

HEATER HOSE ASSEMBLIES

ALSO KNOWN AS: HVAC HEATER HOSE ASSEMBLIES

HIGHLIGHTED COVERAGE

APPLICATIONS	DORMAN #
Buick 2005-00, Chevrolet 2005-00, Pontiac 2003-00	626-113
Cadillac 2000-99, Chevrolet 2000-96, GMC 2000-96	626-105
Chevrolet Cavalier 2002-98, Pontiac Sunfire 2002-98	626-523
Chevrolet Equinox 2005	626-104
Chevrolet Malibu 2006-04, Pontiac G6 2006-05	626-549
Chrysler 2005-01, Dodge 2005-01	626-301
Chrysler 2007-01, Dodge 2007-01	626-309
Chrysler 2008-01, Dodge 2008-01	626-304
Chrysler 2010-01, Dodge 2010-01, Volkswagen 2010-09	626-305
Chrysler Sebring 2006-01, Dodge Stratus 2006-01	626-512
Chrysler Town & Country 2009-08, Dodge Grand Caravan 2009-08, Volkswagen Routan 2010-09	626-307
Chrysler Town & Country 2009-08, Dodge Grand Caravan 2009-08, Volkswagen Routan 2010-09	626-307HP
Chrysler Town & Country 2010, Dodge Grand Caravan 2010	626-314HP
Chrysler Town & Country 2016-11, Dodge Grand Caravan 2016-11	626-315HP
Dodge Durango 2003-01	626-555
Dodge Journey 2010-09	626-561
Ford 2000-99	626-212
Ford 2003-97, Lincoln 2002-98	626-229
Ford 2004-00	626-211
Ford 2004-97, Lincoln 1999-98	626-218
Ford 2004-97, Lincoln 1999-98	626-219
Ford Explorer 2010-06, Mercury Mountaineer 2010-06	626-522
Ford Explorer 2010-06, Mercury Mountaineer 2010-06	626-551
Ford Focus 2004-00	902-206
Ford Taurus 2000-96, Mercury Sable 2000-96	626-209
Ford Taurus 2003-00, Mercury Sable 2003-00	626-207
Ford Taurus 2007-04, Mercury Sable 2005-04	626-513
Ford Windstar 2003-99	626-210
Ford Windstar 2003-99	626-225
Jeep Liberty 2006-02	626-516

Highlighted rows mean OE Fix

Think It's Dealer Only? **Check Dorman First!**