1993 Dodge or Ram Truck D 250 Pickup L6-359 5.9L DSL

Vehicle > Powertrain Management > Fuel Delivery and Air Induction > Relays and Modules - Fuel Delivery and Air Induction > Main Relay (Computer/Fuel System) > Description and Operation > Components

AUTO SHUT DOWN (ASD) RELAY



Engine Compartment Wiring

The fuel pump relay is the shut down relay.

The ASD relay in located on the left inner fender panel in the engine compartment. It provides battery voltage to the generator field winding to provide regulation of the charging system. It is controlled by the PCM, which switches the ASD relay ground circuit on and off.